


Sofa & Upholstered Products

Product Care & Maintenance Guide



Product Care & Maintenance Guide

To fully enjoy the performance and comfort of your Benel sofa and upholstered products, general care and maintenance is essential. When in doubt, always test out on a small inconspicuous area. For additional guidance, please feel free to reach out to our Customer Service Department.

Benel Customer Service Department:
+65 6873 1118 // customercare@benel.com.sg



Upholstery

Vacuum to pick up dust and dirt in the upholstered fabric. With a soft brush, brush the fabric to remove visible matters such as hair, dirt, and dust. Cleaning is not recommended on light-coloured fabrics.




Metal Frame and Parts

For general cleaning and maintenance, a damp cloth will be sufficient. Do not use solvents to clean the metal parts.



Safe Usage

The sofa should be placed 5 to 10cm from the wall to avoid friction between the sofa and the wall. Keep sharp tools away from the furniture. To prevent potential damage to the structure, do not sit on the armrests or backrests.



Relocating Furniture

All furniture should be picked up and not dragged. Disassembling tables, desks, and linked furniture is recommended for easy relocation. Please get in touch with our Customer Service Department for guidance if there is a requirement for relocating or reconfiguring workstations.



Recommended Maintenance

If any components appear loose, investigate without delay, and tighten appropriate fixings where possible. Please do not hesitate to contact our Customer Service Department for further guidance on a solution.